

## Distinctive Characteristics

Low profile body of MRF model accommodates space limitations required for PCB mounting. Behind panel body depths ranging from .323" to .669" (8.2mm to 17.0mm) for MRA and MRK bushing mount models.

Positive detent mechanism for distinct feel and audible feedback.

Metal bushing and housing construction increases durability.


Adjustable stopper plate allows 2–12 position settings.

High contact reliability achieved by the self-cleaning contact mechanism.


Break-before-make contact timing with sliding contacts in MRA and rotary contactor disk in MRF and MRK models.

Interior housing seal and molded-in PC terminals, plus shaft rubber o-ring on MRF and MRK and polyamide cover on MRF model, allow cleaning after automated soldering.

Exterior rubber washer and double flatted bushing on MRA and MRK give protection in splashproof applications.



Actual Size





# General Specifications

## **Electrical Capacity (Resistive Load)**

For MRA: 250mA @ 125V AC or 48V DC

For MRF or MRK: 0.4VA maximum @ 28V AC/DC maximum

(Applicable Range 0.1mA ~ 0.1A @ 20mV ~ 28V)

Note: Find additional explanation of operating range in Supplement section.

Other Ratings

**Contact Resistance:** 10 milliohms maximum for MRA; 50 milliohms maximum for MRF & MRK

**Insulation Resistance:** 100 megohms minimum @ 500V DC

Dielectric Strength: 1,000V AC minimum for 1 minute minimum for MRA

500V AC minimum for 1 minute minimum for MRF & MRK

Mechanical Life: 30,000 operations minimum **Electrical Life:** 10,000 operations minimum

 $0.02 \sim 0.07$ Nm for MRA;  $0.005 \sim 0.02$ Nm for MRF & MRK Range of Operating Torque:

> **Contact Timing:** Nonshorting (break-before-make)

> > MRA - self-cleaning, sliding contact; MRF & MRK - self-cleaning, rotary contactor disk

Indexing: 30°

**Materials & Finishes** 

Shaft: Brass with nickel plating

Stopper Plate: Steel with zinc plating for MRA & MRK; polyamide cover with stopper for MRF

**Bushing/Housing:** Zinc alloy with zinc plating

**Movable Contacts:** Copper with silver plating for MRA; phosphor bronze with gold plating for MRF & MRK **End Contacts & Terminals:** Brass with silver plating for MRA; phosphor bronze with gold plating for MRF & MRK **Common Contacts & Terminals:** Brass with silver plating for MRA; phosphor bronze with gold plating for MRF & MRK

> Base: Diallyl phthalate for MRA; fiberalass reinforced polyamide for MRF & MRK

**Environmental Data** 

-10°C through +70°C (+14°F through +158°F) **Operating Temperature Range:** 

> **Humidity:** 90 ~ 95% humidity for 96 hours @ 40°C (104°F)

Vibration: 10 ~ 55Hz with peak-to-peak amplitude of 1.5mm traversing the frequency range

& returning in 1 minute; 3 right angled directions for 2 hours

Shock: 50G (490m/s<sup>2</sup>) acceleration (tested in 3 right angled directions, with 3 shocks in each direction)

Installation

.686Nm (6.08 lb•in) **Mounting Torque:** 

19.6 ~ 29.4N (4.41 ~ 6.61 lbf) for MRA & MRK Cap Installation Force:

**Processing** 

**Soldering Time & Temperature:** Wave Soldering for MRA: See Profile A in Supplement section;

> Wave Soldering for MRF & MRK: 5 seconds maximum @ 270°C maximum. Manual Soldering for MRA: 4 seconds maximum @ 410°C maximum; Manual Soldering for MRF & MRK: 3 seconds maximum @ 350°C maximum.

Cleaning: Automated cleaning recommended. Stopper plate, as well as washers for MRA & MRK, must be in


place to maintain automated cleaning. See Cleaning specifications in Supplement section.


Standards & Certifications

**UL Recognition** MRA, MRF, & MRK models have not been tested for UL recognition or CSA certification. or CSA Certification: These switches are designed for use in a low-voltage, low-current, logic-level circuit.

When used as intended in a logic-level circuit, the results do not produce hazardous energy.








POLES & CIRCUITS				
112	SP with 2-12 Positions			


DP with 2-6 Positions

4P with 2-3 Positions

206

403





For Pl	ain Knob
No Code	Black


#### For Color Tipped Black В White C Red Yellow E Ē Green G Blue н Gray

#### **DESCRIPTION FOR TYPICAL ORDERING EXAMPLE**


**MRA206-A** 



## **ACTUATORS & TERMINALS**








Slotted for Terminal Screwdriver



**Low Profile Shaft Actuated** with PC Terminals



Shaft **Terminal** 


POLES & CIRCUITS						
Pole	Model	Number of Positions	Stopper Settings	Number of Terminals	Schematics	
	MRA112	2-12	2, 3, 4, 12	1 COM, 12 LOAD	A	
SP	MRF112	2-12	2, 3, 4, 12	1 COM, 12 LOAD		
	MRK112	2–12	2, 3, 4, 12	1 COM, 12 LOAD	1 2 3 4 5 6 7 8 9 10 11 12	
	MRA206	2-6	2, 3, 4, 5, 6	2 COM, 12 LOAD	A B	
DP	MRF206	2-6	2, 3, 4, 5, 6	2 COM, 12 LOAD	<i>[/</i>	
	MRK206	2-6	2, 3, 4, 5, 6	2 COM, 12 LOAD	1 2 3 4 5 6 1 2 3 4 5 6	
	MRA403	2-3	2, 3	4 COM, 12 LOAD	A B C D	
4P	MRF403	2–3	2, 3	4 COM, 12 LOAD	////	
	MRK403	2–3	2, 3	4 COM, 12 LOAD	1 2 3 1 2 3 1 2 3 1 2 3	

## POSITION SETTING FOR MRA, MRF, & MRK MODELS

Each switch is supplied with the stopper set for the maximum number of positions allowed for that model. Prior to installation, the desired position setting should be made. Contact factory for continuous rotation.

#### **MRF Models**


- 1. Remove the protective cover from the switch body.
- 2. Turn the shaft counterclockwise to the extreme left by using a screwdriver.
- 3. Inside the cover is a magnifying lens which would be positioned over the number which is to be the maximum position used; when the cover is then snapped into the switch, the projection beside the lens fits into the correct hole for setting the stop.



#### MRK & MRA Models

- 1. Using the actuator knob, turn the shaft counterclockwise to the extreme left. If the shaft is not turned counterclockwise to the extreme left, proper setting cannot be achieved. At this extreme position, the white line on the knob points to the number 1 position shown on the side of the switch.
- 2. Remove the knob from the shaft and loosen the nut far enough to allow raising the stopper plate, plus washer(s), for resetting to the desired position.
- 3. Note the position numbers on the side of the switch; these correspond to the terminal numbers and stopper holes. Insert the stopper in the hole numbered for the maximum desired number of stop settings. Satisfactory switch functioning cannot be assured if the stopper plate is not properly positioned.
- 4. Tighten the nut (beveled side up) firmly against the stopper plate.

#### Standard Mounting Hardware Packaged Loose with Each Switch:





**MRF403** 




## TYPICAL SWITCH DIMENSIONS


#### **MRA** • PC Terminals 1 Pole 2 Pole 4 Pole (0.8) Dia Typ .031 \_(3.0) Dia .118 (3.0) Dia (3.0) Dia M6 P0.75 -(2.3) (3.15) Dia (1.0) .039 (6.0) (9.5) Dia (10.0) (10.0) .394 (16.0) Dia .630 (9.5) Dia (9.5) Dia .374








MRK devices are designed to be panel mounted. Installation without panel mounting will affect reliability. **MRK112** 



## **KNOBS**




AT433 Plain Black



AT4103 Small **Color Tipped** 

Base Material: **Polyester** Base Color: Black


Polyamide Tip Colors: A, B, C, E, F, G, H



AT4104 Large Color Tipped

Base Material: **Polyester** Base Color: Black

Polyamide Tip Colors: A, B, C, E, F, G, H



**Color Codes:** 















## PANEL CUTOUTS & MAXIMUM EFFECTIVE PANEL THICKNESS

#### **Nonsealed Panel**



With Keyway



#### Sealed Panel



With Standard Hardware on Nonsealed Panel: MRA .067" (1.7mm) MRK .087" (2.2mm)

Without Locking Ring on Nonsealed Panel: MRA .098" (2.5mm) MRK .118" (3.0mm)

With Standard Hardware on Sealed Panel: MRK .106" (2.7mm)

#### STANDARD MOUNTING HARDWARE

## AT513M Metric Hexagon Nut


Material: Brass, nickel plated 1 for MRA; 1 for MRK





#### AT507M **Metric Locking Ring**


Material: Steel, chromate over zinc plating 1 for MRA; 1 for MRK



#### AT509 Lockwasher

Material:

Steel, chromate over zinc plating 1 for MRA; 1 for MRK




(0.5) .020

## AT535 **Rubber Ring**

Material:

Nitrile butadiene rubber 1 for MRK








## OPTIONAL SUPPORT BRACKET

#### AT543 Support Bracket for MRK

Material: Steel with tin plating







A support bracket is needed when the MRK is mounted only to a PC board and does not have the bushing through a panel.